


Ceiling Fan (Twister-D) Wifi Setup

Step 1

- 1) Turn off fan switch
- 2) Wait for 10 seconds
- 3) Turn on fan switch

Step 2




Point the remote at the fan.
Hold the "Light" button for 5
seconds.

Fan light will turn on.


Fan is in pairing mode.

Step 3




Tap the top right + to add device.

Step 4




Select the correct item.

Step 5




Choose 2.4G network and key in the correct password.

Step 6



Tap the red circled icon.

Step 7



Tap the red circled icon.

Wait for the pairing to be set up.

If pairing is un-successful, please follow step 1 again.